



# Easy Home System

## Installation Instructions

- PPE Plastic
- 39.5"L x 4.87"W x 2.87"H
- A-Class
- Walk ways, Patios, Gardens ,

- 1) If installing in concrete, start by digging a trench to accommodate for width of channel, as well as 2-3 inches of concrete to be installed on all sides of the system. If installing in soil, start by digging a trench at least the height and width of your system. If possible, we recommend installing a compacted gravel base under the channels to prevent them from sinking into the ground over time.
- 2) If connecting to underground piping, connect channel system to pipes using an adapter paired to outlet end cap or bottom outlet adapter, using silicone sealant at connection points.
- 3) Connect channels together with snap and lock connection, as well as silicone sealant for a water tight seal.
- 4) Once all channels have been placed inside of trench, attached closed end cap with silicone sealant.
- 5) For soil application, simply fill any openings around channel with loose soil then compact soil for your finished result. For concrete application, apply grate tape to the top of system to protect against concrete splatter. Embed system on all side with concrete mixture. Allow time for concrete to harden. Once concrete is set, remove grate tape for a clean finish to your new trench drain system.

Concrete Video



Grass Video

