



# Mini Slot SLIM Channel System

## Installation Instructions

- 304 Stainless Steel
- 3.9 Feet ( 39 Inches) Long
- A-D Class
- Pools, Patios, Driveways, etc.

- 1) Start by digging a trench to accommodate for width of channel, as well as 2-3 inches of concrete to be installed on all sides of the system.
- 2) Connect slot drain channel system to underground piping from connected outlet end cap end cap or inline basin, using silicone sealant at connection points.
- 3) Attach (2) mounting brackets (if being used) per channel body. Pair (2) rebar rods to each mounting bracket to support and level your system.
- 4) Slide connectors along the length of channel to connect channels to each other. Use silicone sealant at these connection points, along with the connector pieces, for a water tight seal.
- 5) Once all channels have been placed inside of trench, attached closed end cap with silicone sealant, and place slot grate covers (if utilizing) on top of the slot drain system.
- 6) Apply grate tape to the top of system to protect against concrete splatter. Embed system on all side with concrete mixture.
- 7) Allow time for concrete to harden. Once concrete is set, remove grate tape for a clean finish to your new slot drain system.

**Installation Video**



3120 Riverport Tech Center Dr.  
Maryland Heights, MO 63043

Please call with any questions!  
314-717-1551