



# Wall Slot Channel System

## Installation Instructions

- 3.9 Feet ( 39 Inches) Long
- A-D Class
- Pools, Patios, Driveways, etc.

- 1) Start by digging a trench to accommodate for width of channel, as well as 2-3 inches of concrete to be installed on all but one side of the system.
- 2) Connect channel system to underground piping using an adapter paired to outlet end cap, bottom outlet, or inline basin, using silicone sealant at connection points.
- 3) Attach (2) wall mounting brackets (if being used) per channel body. Pair (2) rebar rods to each mounting bracket to support and level your system.
- 4) Connect channels together with snap and lock connection, as well as silicone sealant for a water tight seal.
- 5) Once all channels and slot grates have been placed inside of trench, attached closed end cap with silicone sealant, and place slot grate covers (if utilizing) on top of the slot drain system.
- 6) Apply grate tape to the top of system to protect against concrete splatter. Embed system on all side with concrete mixture. If installing with tile or pavers, allow room to set tiles or pavers on top of concrete so the finished surroundings are flush to the slot opening.
- 7) Allow time for concrete to harden. Once concrete is set, remove grate tape for a clean finish to your new slot drain system.

**Installation Video**



3120 Riverport Tech Center Dr.  
Maryland Heights, MO 63043

Please call with any questions!  
314-717-1551